



Manual do usuário

User's Manual

Super Drum – bateria 3 em 1 • JS054

MULTILASER



Super Drum - bateria 3 em 1



2

Este é um controle para jogos de músicas e pode ser usado para o jogo Rock Band no PS2, PS3 e Wii.

Função:

1. Instrução de uso para PS2 e PS3

Conecte o console no PS2 e PS3. Insira o CD do jogo Rock bando, vire a chave da bateria para a posição PS2 ou PS3 (conforme imagem abaixo), conecte o cabo USB da bateria no console e em seguida conecte o pedal na entrada correspondente. Use a baqueta para bater em diferentes cores da bateria para selecionar as cores correspondentes com o jogo.



Super drum – bateria 3 em 1

2. Instrução de uso para Wii

Conecte o console no Wii. Insira o CD do jogo Rock Band, vire a chave da bateria para a posição Wii (conforme imagem abaixo), conecte o cabo USB da bateria no console e em seguida conecte o pedal na entrada correspondente. Use a baqueta para bater em diferentes cores da bateria para selecionar as cores correspondentes com o jogo.



IMPORTANTE! Ao instalar a bateria, verifique se a chave lateral está indicando o video game correto a ser usado! Se você for usar a bateria no Wii, certifique-se que a chave esteja virada para a indicação do mesmo. Se você for usar a bateria PS2 ou PS3, certifique-se que a chave esteja virada para a indicação do mesmo.

Atenção:

1. Não deixe o produto em contato com líquidos.
2. Não bater fortemente este produto e não colocar pressão sobre ele.
3. Não use ou guarde este produto em alta temperatura ou ambiente úmido.
4. Não puxe o cabo muito forte.



Super Drum - 3 in 1



This is a controller of Music Games, the mini Jazziness Drum can be enjoyed on the table with cupules under the drum pad and it can play Rock Band Game on PS2®, PS3® and Wii®.

Function:

1. Operation instruction for PS2 and PS3 console

Connect the PS2 or PS3 console. Put in PS2 or PS3 Rock Band Game Disk, turn the drum controller's switch to PS2 or PS3 position, plug in the drum controller's USB connector to the console, and then plug in PVC Material pedal connector to



Super drum – bateria 3 em 1

the controller's corresponding port. Use the drum stick to hit on different color of the drum pad to select correspond color from the game interface.

2. Operation instruction for WII console

Connect WII console. Put in WII Rock Band Game Disk, and enter Rock Band game using WII remote. Turn the drum controller's switch to WII position, plug in the drum controller's USB connector to the console, and then plug in PVC material pedal connector to the controller's corresponding port. Use the drum stick to hit on different color of the drum pad select correspond color from the game interface.



IMPORTANT! When installing the battery, make sure the side key is pointing the right video game used! If you use the battery on the Wii, make sure the switch is turned to indicate the same. If you use the battery PS2 or PS3, make sure the switch is turned to indicate the same.

Caution:

1. Do not let the product contact with liquid.
2. Do not hit this product strongly and do not put heavy pressure on it.
3. Do not use or keep this product in high temperature or moist environment.
4. Do not pull the cable too strongly.





www.multilaser.com.br

MULTILASER

